

User Guide for the Vaddio Venture VideoBAR Remote

September 2024
RMT-50909 (Worldwide)

The Vaddio Venture VideoBAR Remote provides basic camera and conference functionality – pan, tilt, zoom, presets, volume control, and muting, as applicable. You can also use the remote to get the camera's IP address. This remote is a radio-frequency device, and is required to be paired with an individual VideoBAR to work. The remote ships already paired to the VideoBAR it is packaged with.

Before you can use the remote, you will need to:

- Install the batteries
- Power on the camera

Installing the Batteries

The remote uses two AAA batteries.

1. Remove the cover from the back of the remote using the tab.
2. Install the batteries as shown in the diagram in the battery opening.
3. Slide and snap the cover back into place.



Pairing the Remote to the VideoBAR

The remote that ships with the VideoBAR already comes paired together, but if you get a replacement remote or swap remotes between units and wish to create a new pairing, do the following:

To remove pairing on a remote that was previously paired to another unit:










1. Press and hold the Menu (≡) and Home (⏠) buttons at the same time until the remote control indicator is solid red
2. Release the buttons to clear the paired status of the remote control.

To pair a remote to the VideoBAR camera:








1. Use a slender item such as a SIM card ejector or a straightened paper clip to press the recessed button on the back of the VideoBAR until the status light on the front sequences a blue dot from left to right.
2. While the camera's status light is still displaying the blue left-to-right pattern (this pairing mode lasts 15 seconds), press and hold the Menu (≡) button until the entire VideoBAR status light flashes blue.
3. Test the control functions to confirm that the items are paired. If you missed the pairing window you may need to reenter the remote control pairing mode and try again.

Venture VideoBAR Remote Quick Reference

The remote may have controls for capabilities that your camera does not have. Some buttons behave in different ways depending on the camera's status.

	<p>Video mute – Stop or resume sending video.</p>
	<p>Power – Power the unit up or enter power-saving mode.</p>
	<p>Call – Answer an incoming call.</p>
	<p>End call – Leave the call.</p>
	<p>Pan-tilt-home – Camera control and menu navigation. Camera control: Press the pan-tilt ring to move the camera in the corresponding direction. Press the Home (⌂) button to return to the centered position. Menu navigation: When navigating the on-screen menu press the pan-tilt ring to move up and down, and press Home to select.</p>
	<p>Volume – Increase or decrease the speaker volume.</p>
	<p>Zoom – Increase or decrease the zoom.</p>
	<p>Mute microphone – Stop or resume sending audio.</p>
	<p>Mute speaker – Stop or resume playing far-end audio into the room.</p>



	<p>Exit tracking – Will stop tracking modes to return to manual PTZ and ePTZ camera operation.</p>
	<p>Speaker tracking – Enable speaker tracking mode.</p>
	<p>Participant tracking – Enable participant tracking mode.</p>
 	<p>Preset 1 and Preset 2 – Set or recall presets.</p>
	<p>Bluetooth – Enable or disable the Bluetooth audio function</p>
	<p>Menu – Display or dismiss the on-screen menu.</p>

Storing and recalling presets

To store a preset:

Set up the shot. Then press and hold the one of the numbered preset buttons for about 5 seconds. If the speaker is not muted, a chime will sound to indicate that the process is complete.

To recall a preset:

Short press the Preset 1 or Preset 2 button.