

Mounting Instructions

Tiltable Universal Screen Bracket


052.1050 / 052.2050 / 052.6050

1


Mounting screen profiles




Mount the screen profiles to the back of the screen. Divide the profiles as well as possible.



2x



* use M4, M5, M6 or M8 mounting material (depending on flat screen) (spacers only if necessary)



2

Ensure there is a minimum distance of least at least 1.5 m between the wall and one side of the mounting plate, to install the locking bar at step 4.

Mounting back plate

A



Mounting back plate to the wall

B



Mounting back plate to the wall (alternative mounting positions)

C



Mounting back plate to truss

D



Mounting back plate to flat screen stand

Mounting Instructions

Tiltable Universal Screen Bracket

052.1050 / 052.2050 / 052.6050

3


Connecting flat screen to base plate



Hook on connecting profiles to the back plate

4

Transit locking bar



1.



2.

1. Transit the locking bar through the 'cheeks' of the back plate.
2. Lock (optional)

5

Tilt adjustment



Turn both knobs to adjust tilting resistance

6




Adjust tilt angle by pushing the screen

1

Montage schermverbinder



Monteer de aanhangprofielen aan het scherm met de montagesleuven aan de onderzijde




2x



a. bout b. sluitring c. manchet d. afstandbus

* afhankelijk van scherm M4, M5, M6 of M8 gebruiken (afstandbus alleen indien nodig)



2


Montage basisplaat

A




Montage basisplaat aan muur

B




Montage basisplaat aan muur (alternatief)

C



Montage basisplaat aan truss

D



Montage basisplaat aan statief

3


Scherm aanhangen aan basisplaat



Zowel boven als onder aanhaken

4


Borgstaaf doorvoeren en afsluiten



1. Borgstaaf door de wangen van de muurplaat en tussen de uitsparingen van de profielen doorvoeren
2. Borgstaaf afsluiten met hangslot (optioneel)

5

Tiltstand borgen en verstellen



Stelknop aan linker- en rechterkant draaien voor het instellen van de tiltweerstand

6

Door tegen de boven- of onderkant van het scherm te duwen kan de tiltstand gewijzigd worden

